

HOW CLEAN EQUIPMENT AND UTENSILS IN A 3 COMPARTMENT SINK

1. PRE-SCRAPE/PRE-FLUSH/PRE-SOAK (IF NECESSARY) EQUIPMENT AND UTENSILS.
2. MAKE SURE ALL SINKS ARE CLEAN AND EACH SINK COMPARTMENT HAS ITS OWN DRAIN STRAINER/PLUG.
3. FILL THE FIRST COMPARTMENT WITH HOT SOAPY WATER.
4. FILL THE MIDDLE COMPARTMENT WITH CLEAN WATER.
5. FILL THE THIRD COMPARTMENT WITH WATER AND SANITIZER. HOW MUCH SANITIZER YOU ADD DEPENDS ON THE SANITIZING AGENT. YOU MAY WANT TO PLACE WATER PROOF TAPE INSIDE OF THE THIRD COMPARTMENT TO DESIGNATE A WATER FILL LINE. YOU MAY WANT TO HAVE A MEASURING CUP/SPOON TO ACCURATELY MEASURE OUT THE SANITIZER.
6. FOR EQUIPMENT AND UTENSILS TOO LARGE TO FIT INTO THE 3 COMPARTMENT SINK, USE THE SAME PROCEDURE AS ABOVE USING THREE SEPARATE BUCKETS.
7. ALL EQUIPMENT AND UTENSILS MUST BE ALLOWED TO AIR DRY.

DURING INSPECTION YOU WILL BE ASKED TO EXPLAIN YOUR UTENSILS/EQUIPMENT CLEANING PROCEDURE, WHAT BRAND OF SANITIZER YOU ARE USING, WHAT THE CHEMICAL SANITIZING AGENT IS AND DEMONSTRATE HOW TO USE AND INTERPRET YOUR SANITIZER TEST STRIPS.

